

Measuring Low Level Ripple Voltage using the Model DMM7510 7½-Digit Graphical Sampling Multimeter

Introduction

Power conversion is a process that exists in all electronic devices. The term “power supply” is loosely interpreted to describe this process, which conditions the power from the primary source to have specific characteristics required by the load. Digital multimeters (DMMs) is a very common instrument used to evaluate many power supply specifications. However, traditional DMMs often lack the capabilities to measure dynamic behaviors, especially those found in the class of switch mode power supplies (SMPSs). An oscilloscope is typically needed to examine the supply’s ripple voltage, switching voltage, power-up glitches, etc. In many cases, an oscilloscope might not offer the resolution needed to correctly characterize the very low level ripple noise. Keithley’s Model DMM7510 7½-Digit Graphical Sampling Multimeter can sample voltages down to 1 μ V or current down to 100pA sensitivity at 1 μ s intervals. In other words, the Model DMM7510 allows you to digitize a variety of dynamic low level voltage and current waveforms with 18-bit accuracy at a 1Mega-sample per second sampling rate. Combining with the instrument’s multi-touch touchscreen interface technology, you can easily capture, view, and interact with both steady-state and dynamic signals from power supplies.

This application note illustrates how to capture, view and characterize the dynamic ripple voltage on a DC-to-DC buck converter on the Model DMM7510’s front panel user interface.

Understanding the basics of a buck converter

A buck converter is a highly efficient switch mode DC-to-DC voltage step down converter. It stores energy in the form of a magnetic field on an inductor. In the “ON” state, the switch is closed and the input voltage charges up the inductor. In the




Figure 1. DC-DC buck converter operation.

“OFF” state, the switch is open and the inductor discharges the stored energy as current flows through the load.

For the purposes of demonstration, this application note uses Texas Instruments LM25088 DC-to-DC buck converter evaluation board (EVM). It produces a steady 5V output from a 5.5V–36V on the input. Modifications were made to the LM25088 EVM to realize a 50kHz switching frequency that is well below the 600kHz analog bandwidth of the instrument at the 10V range. Refer to the instrument specifications from Keithley’s website (www.keithley.com) for additional analog bandwidth requirements for different voltage and current ranges.

Ripple Noise on the Output Voltage

A small ripple voltage will very likely exist on the output of a buck converter when it is on. This phenomenon is caused by the switching frequency, output capacitance, inductor, load, and any current-limiting features. Because it is an undesirable effect of the design, designers will examine and minimize this noise.

Making Connections from the Buck Converter to the Model DMM7510

The buck converter can be easily connected to the Model DMM7510 using a standard pair of test leads as shown in **Figure 2**. Properly shielded test wires are recommended when measuring low level signals. To conduct the test, the buck converter is powered by a 12V DC linear power supply. A linear power supply provides a much lower noise output than a switching power supply, ensuring that the waveform produced reflects the noise from the DUT rather than the noise from the input. The output of the buck converter is connected to a 3 Ω resistive load.




Figure 2. Ripple voltage test connections.

Setting up the Ripple Voltage Measurement from the Front Panel

The ripple voltage can be easily captured by the Model DMM7510. With only a handful of key strokes to set up the

sampling criteria, you can quickly view the waveform on the DMM's graphical display.

Follow these steps to capture about five 50kHz ripples at a sample rate of 1MSample/s and a sample count of 100 using the Model DMM7510's Digitize Voltage function:

1. Press the **POWER** button on the front panel to turn on the instrument.
2. On the FUNCTIONS swipe screen, select **Digi V** to select the Digitize Voltage measure function.
3. Swipe to display the **SETTINGS** swipe screen.
4. Set the Sample Rate to **1,000,000**.
5. Set the Count to **100**.
6. Swipe to display the **GRAPH** swipe screen.
7. Select the graph icon on the upper right of the swipe screen to open the **Graph** screen.

The screen captures in *Figure 3* directly compare the ripples captured on a Model DMM7510 to a typical mid-range oscilloscope. *Figure 3a* illustrates the buck converter output

when both instruments are configured in DC coupling mode. The Model DMM7510 clearly demonstrates superior range and resolution capabilities than the oscilloscope. On the 10V range, the Model DMM7510 is able to capture a dynamic signal as low as tens of millivolts. However, the oscilloscope is incapable of resolving the signal to this resolution and is further limited by the maximum DC offset on its lowest range.

Figure 3b illustrates the ripple voltage when both instruments are configured in AC coupling mode. Although the oscilloscope can resolve the ripple to some extent, the Model DMM7510 provides far superior accuracy and precision at these very low signal levels.

Analyzing the Ripple Voltage Measurement from the Front Panel

As with any touch screen technologies, you may pinch to zoom with your fingers to change the scale of the graph; you may pan the waveform left or right; you may touch any point on the waveform to show details of the reading including timestamps; you may also enable horizontal and/or vertical cursors to analyze





Figure 3a. DC-coupled ripple voltage from the Model DMM7510 (left) and from a typical mid-range oscilloscope (right).





Figure 3b. AC-coupled ripple voltage from the Model DMM7510 (left) and from a typical mid-range oscilloscope (right).




Figure 4a. Zooming.






Figure 4b. Panning.



the waveform. *Figure 4* highlights some of the multi-touch interactions that you are able to perform on the Model DMM7510 touchscreen.

The cursors are conveniently located in one of the graph swipe screens. Follow these steps to enable the horizontal cursors for obtaining a quick visual ripple peak-to-peak voltage measurement:

1. Push the **CONT** (Continuous) trigger mode indicator to select the **MAN** (Manual) trigger mode. This stops data acquisition until the **TRIGGER** key is pressed.
2. Swipe the bottom of the graph screen until the **Cursor** enable button appears.
3. Push the Cursor button a couple of times until **Horiz** is displayed. The horizontal cursors will appear on the graph.
4. Push and drag the yellow horizontal cursor lines to the ripple peaks.
5. The ΔY value shown on the graph swipe bar gives the ripple peak-to-peak value.




Figure 4c. Data point.





Figure 4d. Horizontal cursors.

Saving Data to a USB Drive

To save the ripple voltage readings to a thumb drive, start by inserting a USB thumb drive into the USB port on the left side of the front panel. Press the **MENU** key. Select **Reading Buffers**, press the desired buffer, and then press **Save to USB**. You can customize the name of the file. The data will be saved in the .csv format so it can later be downloaded and imported into a spreadsheet. **TIP:** Press the **HOME** and the **ENTER** keys on the front panel at the same time to save a screen capture to a USB thumb drive.



Setting Up the Ripple Voltage Measurement using SCPI Commands

The following SCPI command sequence will perform the exact same ripple voltage measurement as that performed using the front panel controls. At the end of the command execution, you will see the same waveform displayed on the front panel as shown in *Figures 3* and *4*.

Command	Description
*RST	• Reset the Model DMM7510.
:SENS:DIG:FUNC "VOLT"	• Set the instrument to measure digitize voltage.
:SENS:DIG:VOLT:RANG 10	• Set range to 10V.
:SENS:DIG:VOLT:INP AUTO	• Set the input impedance to 10GΩ.
:SENS:DIG:VOLT:SRATE 1000000	• Set the sample rate to 1e6.
:SENS:DIG:VOLT:APER AUTO	• Enable automatic aperture.
:SENS:DIG:COUN 100	• Set the sample count to 100.
:TRAC:POIN 100	• Set defbuffer1 to store 100 points.
:TRAC:CLE	• Clear defbuffer1.
:TRAC: TRIG: DIG	• Digitize the signal.
:TRAC:DATA? 1, 100, "defbuffer1", READ	• Read the first 100 measurement and relative timestamp values from defbuffer1.
:TRAC:DATA? 1, 100, "defbuffer1", REL	

Setting Up the Ripple Voltage Measurement Using TSP Commands

The following TSP script is designed to run from Keithley's Test Script Builder (TSB) software. TSB is a free software tool that can be downloaded from Keithley's website (www.keithley.com). By default, the Model DMM7510 is configured to use the SCPI command set. You must select the TSP command set before sending TSP commands to the instruments. Follow these steps to change the command set: Press MENU -> Settings -> Command Set. Select TSP commands.

Like the SCPI commands, these TSP commands will perform the exact same ripple voltage measurement by configuring the sample rate to 1MS/s and the sample count to 100 using the digitize voltage function. The same waveform shown in *Figures 3* and *4* will be displayed on the front panel at the end of the script execution.

```

--Reset the instrument to default settings.
reset()
--Create a local variable to store the number of samples
numofsamples = 100
--Set the measure function to digitize voltage to capture
the ripple waveform
dmm.digitize.func = dmm.FUNC_DIGITIZE_VOLTAGE
--Voltage range must be fixed when using digitize voltage
dmm.digitize.range = 10
--Set sample rate to 1 Msample per second to sample a 50
kHz voltage ripple
dmm.digitize.samplerate = 1e6
--Set aperture to auto to get the highest accuracy
measurement for the
    configured sampling rate
dmm.digitize.apertw:e = dmm.APERTURE_AUTO
--Set sample count to the number of samples to capture
about 5 ripples
dmm.digitize.count = numofsamples
--Set the input impedance to auto so it selects 10 G for
the 10V range
dmm.digitize.inputimpedance = dmm.IMPEDANCE_AUTO
--Set the buffer to align with the number of samples
(optional)
defbufferl.capacity = numofsamples
--Clear buffer
defbufferl.clear()
--Make sure your signal is connected to the DMM. Digitize
now.
dmm.digitize.read()

--Print the digitized readings
if defbufferl.n > 0 then
    print("Ripple Voltage:")
    print("Total Count:", defbufferl.n)
    printbuffer(1, defbufferl.n, defbufferl)
    print("Timestamps:")
    printbuffer(1, defbufferl.n, defbufferl.
relativetimestamps)
else
    print ("No data collected")
end
print ("Test Ended")

```

Conclusion

The Model DMM7510 7½-Digit Graphical Sampling Multimeter is the ideal instrument for capturing very- low level DC and dynamic voltage and current signals on power supplies. The touchscreen user interface allows users to view, analyze, and interact with the waveform right on the instrument. It is compact, simple to set up and a perfect must-have instrument for your bench.

Specifications are subject to change without notice. All Keithley trademarks and trade names are the property of Keithley Instruments. All other trademarks and trade names are the property of their respective companies.



A Greater Measure of Confidence

KEITHLEY INSTRUMENTS ■ 28775 AURORA RD. ■ CLEVELAND, OH 44139-1891 ■ 440-248-0400 ■ Fax: 440-248-6168 ■ 1-888-KEITHLEY ■ www.keithley.com

BENELUX
+31-40-267-5506
www.keithley.nl

FRANCE
+33-01-69-86-83-60
www.keithley.fr

ITALY
+39-049-762-3950
www.keithley.it

MALAYSIA
60-4-643-9679
www.keithley.com

SINGAPORE
01-800-8255-2835
www.keithley.com.sg

BRAZIL
55-11-4058-0229
www.keithley.com

GERMANY
+49-89-84-93-07-40
www.keithley.de

JAPAN
81-120-441-046
www.keithley.jp

MEXICO
52-55-5424-7907
www.keithley.com

TAIWAN
886-3-572-9077
www.keithley.com.tw

CHINA
86-10-8447-5556
www.keithley.com.cn

INDIA
080-30792600
www.keithley.in

KOREA
82-2-6917-5000
www.keithley.co.kr

RUSSIA
+7-495-664-7564
www.keithley.ru

UNITED KINGDOM
+44-1344-39-2450
www.keithley.co.uk

For further information on how to purchase or to locate a sales partner please visit www.keithley.com/buy